



**Perform and record lab surveys as needed (monthly and post experiment)**

**Avoid generating mixed waste (combinations of radioactive, biological and chemical waste)**

**Special Precautions:**

**Store behind 1.2 cm lead shielding when working with Kr-85**

**Use tools to indirectly handle unshielded sources and potentially contaminated containers - no direct hand contact**

**Ensure that an appropriate, operational survey meter is present in the work area and turned on whenever I**